

We thank you and congratulate you for choosing BOS products, designed and developed by enthusiasts, and handmade with care in France.

Please refer to the user manual available in the download section at www.bosmtb.com. It contains the important safety, maintenance, and warranty information you will need in order to safely install and use your BOS suspension as well as detailed set-up, tuning, and service information.

Good knowledge of your BOS product will make its day to day usage more enjoyable.

Air pressure

Whatever your weight, the air pressure should be between 120 and 220 psi.

Note : Given pressures are for guidance only. You can adjust it ± 10 psi according to your use and your riding style.

Weight (kg/lbs)	60/132	65/143	70/154	75/165	80/176	85/187	90/198
Recreational Use : Pressure (psi)	120	130	140	150	160	170	180
Racing Use : Pressure (psi)	125	135	145	155	165	175	185

Balancing air chambers

It is important to balance the pressure of the air chambers during each pressure adjustment to ensure optimum performance. To do this, compress and slowly release your fork for the first 10 mm of travel a dozen times.

Starting point adjustments : To start your adjustment, turn the knob clockwise until it stops (=clic 0). Then, clicks are counted turning the knob in the counterclockwise direction.



Rebound (A) :

Recreational use : 10 clicks

Racing use : 8 clicks

Compression (B) : 3 Positions

- **Soft** : comfort
- **Intermediate** : hydraulic and grip control (Adjustable intensity : refer to the user manual).
- **Hard** : pedaling efficiency



Important : Refer to the user manual for instructions to mount the axle. This is essential for your safety.